

Bovie Aaron 940

High Frequency Desiccator

Equipment for the way *you* operate



Less to buy, less to do...

With the Aaron 940, the same 3-Button Pencil works with or without the optional footswitch! And you simply plug in the optional footswitch and you are ready to go! Not only is the Bovie footswitch much more cost effective, but you don't need to replace the handpiece like you do on other devices. You have complete control including up/down power from the handpiece.



Foot control handpiece and footswitch are sold separately and are both required for the ConMed® foot control option.

Competing desiccators can require too many time-wasting steps...



STEP 1
Unplug 3-button handpiece from bottom of unit



STEP 2
Unplug 3-button handpiece from front of unit



STEP 3
Detach 3-button handpiece from holder



STEP 4
Attach foot control handpiece



STEP 5
Plug foot control handpiece into front of unit



STEP 6
Plug footswitch into bottom of unit

...even more steps to go from low to high power, and just as many to return to low again!



STEP 1
Unplug the handpiece from the Lo power receptacle



STEP 2
Move the power selector switch from Lo to Hi



STEP 3
Plug the handpiece into the Hi power receptacle



STEP 4
Adjust the rotary dial or up/down buttons on the handpiece

VS



Power Control with the Aaron 940@

Simply change the power setting with one action, using the rotary power-control dial or the up/down buttons on the autoclavable handpiece!